

Pre-recovery **Safety** Instructions for  
Custom **Slitting** Apparatus



**FluoroPEELZ™**  
PEELABLE SLIT GUIDE

Zeus, headquartered in Orangeburg, South Carolina, is the world's leading polymer extrusion and catheter design manufacturer. With over 55 years of experience in medical, aerospace, energy, automotive, fiber optics, and other leading industries, Zeus's mission is to provide solutions, enable innovation, and enhance lives. The company employs over 2,400 people worldwide with facilities in Aiken, Columbia, Gaston, Orangeburg, and St. Matthews, South Carolina; Branchburg, New Jersey; Chattanooga, Tennessee; San Jose, California; Arden Hills, Minnesota; Guangzhou, China; and Letterkenny, Ireland. For more information, visit [www.zeusinc.com](http://www.zeusinc.com).



**AMERICAS:** +1 803.268.9500

**EUROPE:** +353 (0)74 9109700 | **ASIA/PACIFIC:** +(86)20-38254906

[support@zeusinc.com](mailto:support@zeusinc.com) | [www.zeusinc.com](http://www.zeusinc.com)

**PLEASE  
EXERCISE  
CAUTION  
WHEN  
HANDLING THE  
BLADE. ZEUS  
RECOMMENDS  
SLITTING BOTH  
ENDS OF  
FluoroPEELZ™  
PRIOR TO  
RECOVERY.**

### Nothing compares to one simple tear with FluoroPEELZ™.

The following are procedures recommended for using the slit fixture. Deviations from these procedures may result in injury and / or excess waste. Users should also review their company safety rules and applicable safety laws and regulations.

**SPECIAL NOTE:**

Hole sizes can be laser marked for identification.

### To install a new blade:

1. Cut-resistant gloves should be worn
2. Loosen the two blade retaining screws from the side of the fixture.
3. Remove blade from the fixture and discard in a sharps container.
4. Lightly tighten the two blade retaining screws to secure the new blade in the fixture.

### To Slit part:

1. Insert the FluoroPEELZ™ tube into the smallest hole that it will fit freely.
2. Push the FluoroPEELZ™ into the blade until it hits the back of the razor blade and stops.
3. Remove the slit FluoroPEELZ™ from the fixture.

### To Peel (Post-Recovery):

1. Firmly grasp one side of the slit FluoroPEELZ™ in each hand.
2. Pull each half of the FluoroPEELZ™ away from each other in a manner that is perpendicular to the catheter; pull steadily with an even motion removing equal amounts of FluoroPEELZ™ in each hand.
3. Stop and re-grasp FluoroPEELZ™ nearer to the catheter as needed to maintain even and steady removal.

