

Pre-recovery **Safety** Instructions for Custom **Slitting** Apparatus



FluoroPEELZ®

PEELABLE SLIT GUIDE

PLEASE EXERCISE CAUTION WHEN HANDLING THE BLADE. ZEUS RECOMMENDS SLITTING BOTH ENDS OF FluoroPEELZ® PRIOR TO RECOVERY.

Nothing compares to one simple tear with FluoroPEELZ®.

The following are procedures recommended for using the slit fixture. Deviations from these procedures may result in injury and / or excess waste. Users should also review their company safety rules and applicable safety laws and regulations.

SPECIAL NOTE:

Hole sizes can be laser marked for identification.



- OVER 50 YEARS OF INDUSTRY SOLUTIONS -

Zeus delivers precision polymer solutions that transform businesses, markets, and lives. We have dedicated ourselves to building partnerships, products, and services for the benefit of our customers.

Headquartered in Orangeburg, South Carolina, Zeus employs approximately 1,500 people and operates multiple facilities around the world.



Americas +800.526.3842
Europe +353 (0)74 9109700 | Asia/Pacific +(86) 20-38254909
support@zeusinc.com | zeusinc.com

To install a new blade:

1. Cut-resistant gloves should be worn
2. Loosen the two blade retaining screws from the side of the fixture.
3. Remove blade from the fixture and discard in a sharps container.
4. Lightly tighten the two blade retaining screws to secure the new blade in the fixture.

To Slit part:

1. Insert the FluoroPEELZ® tube into the smallest hole that it will fit freely.
2. Push the FluoroPEELZ® into the blade until it hits the back of the razor blade and stops.
3. Remove the slit FluoroPEELZ from the fixture.

To Peel (Post-Recovery):

1. Firmly grasp one side of the slit FluoroPEELZ® in each hand.
2. Pull each half of the FluoroPEELZ® away from each other in a manner that is perpendicular to the catheter; pull steadily with an even motion removing equal amounts of FluoroPEELZ® in each hand.
3. Stop and re-grasp FluoroPEELZ® nearer to the catheter as needed to maintain even and steady removal.